






Designation converter of the insert ball bearings housing units

MARKING		SG	FG	FM
 <p>UC</p>	ZVL	SGC	FGC	FMC
	SKF	SYJ.TF	FYJ.TF	FYTJ.TF
	FKL	LES	LEF	LEN
	INA	RASEY	RCJ	RCJT
	FAG	SG362	FG362	-
	KOYO	UCP	UCF	UCFL
	NSK	UCP	UCF	UCFL
	NTN	UCP	UCF	UCFL
 <p>UA</p>	ZVL	SGA	FGA	FMA
	SKF	SYJ.WF	FYJ.WF	FYTJ.WF
	FKL	LYS	LYF	LYN
	INA	RASE	RCJ	RCJT
	FAG	SG362.B	FG362.B	-
	KOYO	NAP	NAF	NAFL
	NSK	EWP	EWF	EWFL
	NTN	UELP	UELF	UELFL

Designation converter of the insert ball bearings housing units

MARKING		SG	FG	FM
 <p>UE</p>	ZVL	SGE	FGE	FME
	SKF	SYJ.FM	FYJ.FM	FYTJ.FM
	FKL	UYS	UYF	UYN
	INA	PASE	PCI	PCJT
	FAG	SG162	FG162	-
	KOYO	SAP	SAF	SAFL
	NSK	ENP	-	-
	NTN	AELP	AELF	AELFL
 <p>US</p>	ZVL	SGD	SGD	SGD
	SKF	-	-	-
	FKL	USS	USF	USN
	INA	-	-	-
	FAG	SG762.B	FG762.B	-
	KOYO	-	-	-
	NSK	UBP	ASF	ASFL
	NTN	-	-	-

Designation converter of the insert ball bearings housing units

MARKING		SG	FG	FM
 <p>UD</p>	ZVL	SGS	FGS	FMS
	SKF	SYJ.RM	FYJ.RM	FYTJ.RM
	FKL	UES	UEF	UEN
	INA	PASEY	PCJY	PCTTY
	FAG	-	SBF	SBFL
	KOYO	SBP	UBF	UBFL
	NSK	UBP	ASF	ASFL
	NTN	-	-	-